




# PHASE SHIFT CONTROL RC BASE USING SCR & TRIAC MODEL - PWR14

This trainer has been designed with a view to provide practical and experimental knowledge of Phase shift control RC base using SCR & TRIAC.



## SPECIFICATIONS

1. Power supply requirement : 230V AC, 50 Hz.
2. Following parts provided on Single PCB with connecting terminals.  
Diac - DB3 - 1 No.  
Triac - BT136 - 1 No.  
100K Ohm Variable Resistor (Potentiometer)  
SCR - Bt151- 1No.  
22K ohm Variable Resistor (Potentiometer)
3. Standard Accessories :
  1. A Training Manual
  2. Connecting Patch cords.

In keeping view of SIGMA policy of continuous development and improvement, the Specifications may be changed without prior notice or obligation.

**Sigma Trainers and Kits**  
E-113, Jai Ambe Nagar,  
Near Udgam School,  
Thaltej,  
**AHMEDABAD - 380054.**  
**INDIA.**

**Phone(O): +91-79-26852427/ 26850829**  
**Phone(F): +91-79-26767512/ 26767648**  
**Fax : +91-79-26840290/ 26840290**  
**Mobile : +91-9824001168**  
**Email : sales@sigmatrainers.com**  
**: sigmatrainers@sify.com**  
**Web : www.sigmatrainers.com**

**Dealer:-**